```
1 using System;
 2 using System.Management;
 3 using System.IO.Ports;
4 using System.Net;
 6 namespace testProgram
7 {
8
       class MainClass
9
10
           //Local Network Settings Struct
           public struct local_net
11
12
               public string myMode, myHostname, myIPv4, mySubnet, myCIDR,
13
                 myGateway;
14
           }
15
           static void Main()
16
17
           {
               local_net _net = new local_net();
18
19
20
               while (true)
21
22
                   get_info(ref _net);
23
                   var portNames = SerialPort.GetPortNames();
24
25
26
                   foreach (var port in portNames)
27
                   {
28
                       try
29
                       {
30
                           Console.Clear();
                           Console.WriteLine("Configuration Dongle CONNECTED!");
31
32
                           Console.WriteLine
                        ("-----");
33
                           Console.WriteLine("Communicating w/ " + port + "\n");
34
35
                           //Setup COM Port
36
                           SerialPort serialPort = new SerialPort(port, 9600,
                        Parity.None, 8, StopBits.One);
37
                           serialPort.DtrEnable = true;
38
                           serialPort.Open();
39
                           string rcv_data = "", rcv_ip = "", rcv_subnet = "";
40
41
42
                           //Read Request from Dongle
43
                           rcv_data = serialPort.ReadLine();
44
45
                           //Parse Request
                           if (rcv_data == "Mode\r")
46
47
48
                               serialPort.Write(_net.myMode);
49
                               rcv_data = "";
```

```
\underline{\dots} \texttt{Ments} \\ \texttt{Code} \\ \texttt{C\#\_Application (Final Code Project)} \\ \texttt{Program.cs}
```

```
2
```

```
50
51
52
                             else if (rcv_data == "Host\r")
53
54
                                  serialPort.Write(_net.myHostname);
55
                                 rcv_data = "";
56
57
58
                             else if (rcv_data == "IP\r")
59
                                 serialPort.Write(_net.myIPv4);
60
                                 serialPort.DiscardOutBuffer();
61
                                  serialPort.DiscardInBuffer();
62
63
                                 rcv_data = "";
64
                             }
65
                             else if (rcv_data == "Sub\r")
66
67
                             {
                                 serialPort.Write(_net.mySubnet);
68
69
70
                                 serialPort.DiscardOutBuffer();
                                  serialPort.DiscardInBuffer();
71
                                 rcv_data = "";
72
73
                             }
74
75
                             else if (rcv_data == "Gate\r")
76
77
                                 serialPort.Write(_net.myGateway);
78
79
                                 serialPort.DiscardOutBuffer();
80
                                  serialPort.DiscardInBuffer();
                                 rcv_data = "";
81
82
                             }
83
84
                             else if (rcv_data == "DHCP\r")
85
                                 serialPort.Write("OK");
86
87
                                 setDHCP();
88
                                 serialPort.Write("OK");
89
90
                                  serialPort.DiscardOutBuffer();
91
                                  serialPort.DiscardInBuffer();
92
                             }
93
94
                             else if (rcv_data == "Static\r")
95
                             {
                                 serialPort.Write("OK");
96
                                 rcv_ip = serialPort.ReadLine();
97
                                 rcv_ip = rcv_ip.Replace("\r\n", "").Replace("\r",
98
                          "").Replace("\n", "");
99
                                 serialPort.Write("OK");
100
```

```
...ments\Code\C#_Application (Final Code Project)\Program.cs
                                                                                       3
101
                                 rcv_subnet = serialPort.ReadLine();
                                 rcv_subnet = rcv_subnet.Replace("\r\n", "").Replace
102
                         ("\r", "").Replace("\n", "");
103
104
                                 setStatic(rcv_ip, rcv_subnet);
                                 serialPort.Write("OK");
105
106
                                 serialPort.DiscardOutBuffer();
107
108
                                 serialPort.DiscardInBuffer();
109
                             }
110
                             //Debugging purposes prints to console so I can see the
111
                         info
112
                             Console.WriteLine("Hostname: " + net.myHostname);
113
                             Console.WriteLine("IP: " + _net.myIPv4 + "/" +
                         _net.myCIDR);
                             Console.WriteLine("Subnet: " + _net.mySubnet);
114
                             Console.WriteLine("Gateway: " + _net.myGateway + "\n");
115
116
117
                             //close Port
                             serialPort.Close();
118
119
                             break;
120
121
                        catch (Exception ex)
122
                         {
123
                             Console.Clear();
                             Console.WriteLine("Configuration Dongle DISCONNECTED!");
124
125
                             Console.WriteLine
                         ("-----");
                             Console.WriteLine("Error opening port " + port + ": {0}", →
126
                          ex.Message);
127
                         }
128
                    }
129
                 }
130
            }
131
132
            public static void get_info(ref local_net _net)
133
134
                 //Retrieve Hostname
                IPHostEntry hostInfo = Dns.GetHostEntry(Dns.GetHostName());
135
                 _net.myHostname = hostInfo.HostName;
136
137
138
                 //Retrieve IPv4 Address of Hostname
139
                IPAddress[] address = Dns.GetHostAddresses(Dns.GetHostName());
140
141
                //Set network settings struct values to NULL
142
                net.myMode = "No Internet Access";
143
                 _net.myIPv4 = address[1].ToString(); //Default IPv4 address 127.0.0.1 →
                   w/ no network connection
                _net.mySubnet = " ";
144
                _net.myCIDR = " ";
145
                _net.myGateway = " ";
146
```

```
...ments\Code\C#_Application (Final Code Project)\Program.cs
                                                                                         4
147
148
                 //Creating instance of ManagementClass for network adapter settings
                 ManagementClass objMC = new ManagementClass
149
                   ("Win32_NetworkAdapterConfiguration");
150
                 //Gets all the info for all the network adapters
151
152
                 ManagementObjectCollection objMOC = objMC.GetInstances();
153
154
                 //Parse through the info to find the network adapter with Network
                   connection
                 foreach (ManagementObject objMO in objMOC)
155
156
                     //If an IP exists in one of the adapters, then that's the active ▶
157
                       network we are working with
158
                     if ((bool)objMO["IPEnabled"])
159
                     {
160
                         try
161
                         {
                             //Get Mode, IPv4 Address, Subnet Mask, Gateway
162
                             string mode = ((bool)objMO["DHCPEnabled"]).ToString
163
                          ().ToLower() == "true" ? "DHCP" : "Static";
                             string[] ipaddress = (string[])objMO["IPAddress"];
164
                             string[] subnet = (string[])objM0["IPSubnet"];
165
166
                             string[] gateway = (string[])objMO["DefaultIPGateway"];
167
168
                             //Assign struct values w/ the values retrieved from code ₹
                          above
169
                             _net.myMode = mode;
170
                             net.myIPv4 = ipaddress[0];
171
                             _net.mySubnet = subnet[0];
172
                             //Assign Gateway w/ a try function since gateway is
173
                          optional during STATIC mode
174
                             try
175
                                 if (gateway == null)
176
                                     _net.myGateway = "unavailable";
177
                                 else
                                     _net.myGateway = gateway[0];
178
179
180
                             catch (Exception)
181
182
                                 _net.myGateway = "unavailable";
183
                                 throw;
184
                             }
185
                             //Calculate CIDR from Subnet
186
187
                             string[] tokens = net.mySubnet.Split('.');
                             string result = "";
188
189
                             foreach (string token in tokens)
190
```

int tokenNum = int.Parse(token);

string octet = Convert.ToString(tokenNum, 2);

191

192

```
...ments\Code\C#_Application (Final Code Project)\Program.cs
                                                                                          5
193
                                  while (octet.Length < 8)</pre>
194
                                      octet = octet + '0';
195
                                  result += octet;
196
                              }
197
198
                             //Assign CIDR struct
199
                             _net.myCIDR = (result.LastIndexOf('1') + 1).ToString();
200
201
202
                         catch (Exception)
203
204
                              throw;
205
206
                     }
207
                 }
208
             }
209
210
             public static void setDHCP()
211
212
                 //Creating instance of ManagementClass for network adapter settings
213
                 ManagementClass objMC = new ManagementClass
                   ("Win32_NetworkAdapterConfiguration");
214
                 //Gets all the info for all the network adapters
215
                 ManagementObjectCollection objMOC = objMC.GetInstances();
216
217
                 //Parse through the info to find the network adapter with Network
                   connection
                 //If an IP exists in one of the adapters, then that's the active
218
                                                                                          P
                   network we are working with
219
                 foreach (ManagementObject objMO in objMOC)
220
221
                     if ((bool)objMO["IPEnabled"])
222
223
                         try
224
                         {
225
                              //Enable DHCP
226
                              var ndns = objMO.GetMethodParameters
                                                                                          P
                          ("SetDNSServerSearchOrder");
227
                              ndns["DNSServerSearchOrder"] = null;
228
                              objMO.InvokeMethod("EnableDHCP", null, null);
                              objMO.InvokeMethod("SetDNSServerSearchOrder", ndns,
229
                          null);
230
                         }
                         catch (Exception)
231
232
233
                             throw;
234
                         }
235
                     }
236
                 }
237
             }
238
             public static void setStatic(string ip_address, string subnet_mask)
239
```

```
...ments\Code\C#_Application (Final Code Project)\Program.cs
                                                                                          6
240
241
                 //Creating instance of ManagementClass for network adapter settings
                 ManagementClass objMC = new ManagementClass
242
                   ("Win32_NetworkAdapterConfiguration");
243
                 //Gets all the info for all the network adapters
244
                 ManagementObjectCollection objMOC = objMC.GetInstances();
245
                 //Parse through the info to find the network adapter with Network
246
                   connection
247
                 //If an IP exists in one of the adapters, then that's the active
                                                                                         P
                   network we are working with
248
                 foreach (ManagementObject objMO in objMOC)
249
                 {
                     if ((bool)objMO["IPEnabled"])
250
251
                     {
252
                         try
253
                         {
254
                             ManagementBaseObject setIP;
255
                             ManagementBaseObject newIP = objMO.GetMethodParameters
                          ("EnableStatic");
256
                             //Set IPv4 Address and Netmask recieved from
257
                                                                                         P
                          Configuration Dongle
258
                             newIP["IPAddress"] = new string[] { ip_address };
                             newIP["SubnetMask"] = new string[] { subnet_mask };
259
260
261
                              //Enable Static Mode
                             setIP = objMO.InvokeMethod("EnableStatic", newIP, null);
262
263
                         }
264
                         catch (Exception)
265
266
                             throw;
267
                         }
268
                     }
269
                 }
             }
270
271
272
             public static UInt16 ModRTU_CRC(string buf, int len)
273
             {
274
                 UInt16 crc = 0xFFFF;
275
                 for (int pos = 0; pos < len; pos++)</pre>
276
277
                     crc ^= (UInt16)buf[pos];
278
                                                       // XOR byte into least sig.
                       byte of crc
279
280
                     for (int i = 8; i != 0; i--)
                          // Loop over each bit
281
282
                         if ((crc & 0x0001) != 0)
283
                                // If the LSB is set
284
                             crc >>= 1;
                                                            // Shift right and XOR
                                                                                         P
                          0xA001
```

```
...ments\Code\C#_Application (Final Code Project)\Program.cs
                                                                                       7
285
                             crc ^= 0xA001;
286
                        }
                        else
287
                                                         // Else LSB is not set
288
                             crc >>= 1;
                                                           // Just shift right
289
                     }
290
                 }
                 // Note, this number has low and high bytes swapped, so use it
291
                                                                                       P
                   accordingly (or swap bytes)
292
                return crc;
293
            }
294
        }
295 }
296
297
```